

CECTEK



KINGCOBRA / ESTOC

SERVICE MANUAL v1.3

TOPIC

POWER TRAIN

I

ENGINE

II

CHASSIS

III

SUSPENSION / TRANSMISSION

IV

ELECTRICAL

V

MAINTENANCE

VI

SPECIAL TOOLS

VII


POWER TRAIN

Engine Specification.....	P1
Engine Lubrication System.....	P2
Engine Breather System.....	P3
CVT System.....	P4
Start System.....	P5
Injection System.....	P6
Emission Control System.....	P7
Cylinder Head / Block.....	P8
EMS System.....	P9

I

Engine Specification

I



Type : 4 Stroke / Single Cylinder / SOHC / 4 Valves

Displacement : 497cc

Bore x Stroke : ø90mm x 78mm

Compression Ratio : 10.0


Max. rev. : 7500rpm

Transmission : CVT / V-belt

Emission : 2002 / 51 / EC

Weight : 67kg

Engine Lubrication System



Lubrication : Wet Sump

Oil Pump : Rotor Type

Oil Filter : Paper Type

Oil Type : 10w / 40

Oil Volume : 3.0L / 3.5L (Replace Filter)


Pressure Release : 4.5 kg/cm²

Pressure S/W : 0,2 kg/cm²


Oil Inlet : ———→
Oil Return : - - - - -→

Engine Breather System

I



CVT System



CVT Belt Type : DAYCO 5324


Drive Wheel Tightening Torque : 40~45Nm

Driven Wheel Tightening Torque : 120Nm

Ratio : 0.316(min)~1.581(max)

Engine Speed Limit : 7500rpm

Start System




Starter Output : 0.7KW


Operation Voltage : 12V

Temperature Range : -10 ~ +120 °C


Starter Circuit Diagram :



Injection System




I



Emission Control System

I



Emission Relational Part :


ECU / Throttle Body ASM / Spark Plug / Ignition
Coil ASM / O2 Sensor / Catalyst

Catalyst : 100 cells/in²

Catalyst Volume : 116cc

Emission : Updated 2002 / 51 / EC

Cylinder Head / Block




Cylinder Head ASM : Aluminum Alloy < AC4B+T6 >
SOHC / Chain Drive / 4 Valves

Spark Plug Type : Champion PRG7C

Cylinder Block ASM : Liner Material < FC250 >
Aluminum Alloy < ADC12 >

EMS System

Block Diagram




EMS System

CONNECTOR:

A. ON BOARD CONNECTOR: AMP 4-1437290-0

I




ECU connector
viewed from harness side

Pin Assignment

Pin Number	Pin def	Operation Voltage			Operation Current(A) at Voltage(V)	
		Min	Normal	Max	Max	
		V	V	V	mA	V
1	PUMP	9	12	16	4000	16
2	K-LINE	0	N/C	16	50	16
3	CAN_Hi	0	N/C	4.5	100	4.5
4	CAN_Lo	0	N/C	2.25	100	2.25
5	Diagnostic	0	N/C	16	0.5	16
6	5VREF_OUT	4.81	5	5.19	50	5.19
7	5VREF_RETURN / S_GND	N/C	N/C	N/C	N/C	N/C
8	IGN_KEY	9	12	16	500	16
9	12V Power	9	12	16	1000	16
10	O2_HEATER	9	12	16	2000	16
11	Rollover_Switch	0	N/C	16	0.5	5.19
12	Coolant_Gauge	9	12	16	500	16
13	NA	N/C	N/C	N/C	N/C	N/C
14	MIL	9	12	16	500	16
15	Tachometer	9	12	16	500	16
16	NA	N/C	N/C	N/C	N/C	N/C
17	GND	N/C	N/C	N/C	N/C	N/C
18	NA	N/C	N/C	N/C	N/C	N/C
19	Neutral_Switch	0	N/C	16	0.5	5.19
20	IAT	0	N/C	16	5	5.19
21	TPS	0	N/C	16	5	5.19
22	CLT	0	N/C	16	5	5.19
23	O2 Signal	0	N/C	16	5	5.19
24	IACV_AHI	9	12	16	250	16
25	IACV_ALO	9	12	16	250	16
26	IGN_GND	N/C	N/C	N/C	N/C	N/C
27	EST1	9	12	16	13000	16
28	INJ1	9	12	16	2000	16
29	NA	N/C	N/C	N/C	N/C	N/C
30	GND	N/C	N/C	N/C	N/C	N/C
31	S_REF_Hi	0.6	12	80	250	80
32	S_REF_Lo	0.6	12	80	250	80
33	IACV_BHI	9	12	16	250	16
34	IACV_BLO	9	12	16	250	16

ECU


I



Part Introduction

ECU Type : MC21 1030

Assembly :




Electrical Characteristic

Operation Voltage Range : 9~16V

Storage Temperature Range : -40~+70°C

Operation Current : < 500mA

Injector



I


Part Introduction

Identification Code : 28140652

Injector Holes : 4ea

Circuit Diagram :

Main Power Relay



Measurement Resistance : $12.0 \pm 0.6 \Omega$

Throttle Body ASM

I


Idle Air Control Valve
< IACV > (Step Motor)



Throttle Body


Throttle Position Sensor
(TPS)

Throttle Body – TPS 、 Step Motor




Part Introduction

TPS Circuit Diagram :




Step Motor Circuit Diagram :



Measurement TPS Resistance :
1~2Ω (ECU Pin21 + GND)

Rollover (Fuel-Cut) Sensor



Part Introduction


Sensor Voltage : 12V

Sensor Pitch Angle : $65^{\circ} \pm 10^{\circ}$

Sensor Roll Angle : $-20^{\circ} \sim +20^{\circ}$

Sensor Temperature : $-10 \sim +60^{\circ}\text{C}$

Circuit Diagram :




Assembly

Bolt : M4 Bolt x 2

Tighten Torque : 1.5~2.5Nm

Measurement Resistance : 3.9Ω (Vcc + Output)

Fuel Pump



I


Part Introduction

Pump Characteristic Voltage : 12V

Feed Fuel Pressure : $250 \pm 10\text{Kpa}$

Feed Fuel Rate : 30.6 L/hr (min)


Circuit Diagram :



Measurement Resistance : 4~ 10 Ω (Full Stop)

93~100 Ω (Empty Stop)

Ignition Coil




I

Part Introduction

Sensor Characteristic Voltage : 12V

Sensor Temperature : -10 ~ +60 °C

Circuit Diagram :



Assembly

Bolt : M4 Bolt x 2

Tightening Torque : 10 ± 2 Nm




Measurement

Primary : $2.9 \Omega \pm 10\%$

Secondary : $15 K\Omega \pm 10\%$

Alternator

I



Alternator


Part Introduction

Electric Characteristic Voltage : 12V


Output : 16V / 1500rpm ↑

Circuit Diagram

Rectifier :



Crank Sensor :



ENGINE

DISMANTLE

CVT Cover Dismantle.....	P1
CVT Belt Dismantle.....	P2
CVT Driven Pulley Dismantle.....	P2
CVT Driving Pulley Dismantle.....	P3
Rewind Starter Dismantle.....	P4
Timing Check.....	P4
Accessory Cover Dismantle.....	P6
Discompressor Dismantle.....	P7
Alternator Rotor Dismantle.....	P8
Cam Shaft Dismantle.....	P9
Chain Dismantle.....	P11
Cylinder Head Dismantle.....	P12
Balancer Dismantle.....	P13
The Oil Pump Dismantle.....	P14
The Driveshaft Dismantle.....	P15
The Oil Main Circuit Dismantle.....	P17
The Cylinder Block Dismantle.....	P18
The Transmission Gear Dismantle....	P20
The Oil Release Valve Dismantle.....	P22
The Crankshaft Dismantle.....	P23
The Piston Dismantle.....	P24

II

ENGINE

ASSEMBLY

The Piston And Connection Rod Assembly.....	P25
The Balancer Assembly.....	P27
The Main Shaft Assembly.....	P29
The Lay Shaft Assembly.....	P30
The Rear Driveshaft Assembly.....	P32
The Cylinder Head Assembly.....	P33
The Water Pump Assembly.....	P36
The Shift Drum And Fork Assembly..	P37
The Transmission Gear Assembly.....	P38
The Gear Idle Gear Assembly.....	P40
The Crankcase And Cylinder Block Assembly.....	P41
The Bearing And Crankshaft Assembly.....	P45

II

ENGINE - Dismantle

CAUTION :

Only trained and certificated technician can disassembly the CECTEK 500 EFI ENGINE. Improper disassembly may damage the engine. CECTEK can not provide the warranty to the engine which has not been properly disassembled and assembled by trained and certificated technician.

II

CVT COVER DISMANTLE



Loosen the CVT cover bolts




Remove the CVT cover



The CVT cover

ENGINE - Dismantle

CVT BELT DISMANTLE



Tighten the Belt Removal Tool to end to open the driven pulley then removal the belt



The belt


※Reinstall , the installer must can read the printed word on the belt



CVT DRIVEN PULLEY DISMANTLE



Loosen the driven pulley bolt , then remove the driven pulley




The Driven pulley


II

ENGINE - Dismantle


CVT DRIVING PULLEY DISMANTLE



Loosen the driving pulley bolt



Tighten the CVT Puller by air wrench to remove the drive pulley




The drive pulley

II

ENGINE - Dismantle

REWIND STARTER DISMANTLE




Loosen the rewind starter bolts



The rewind starter

TIMING CHECK

※before dismantle engine must be check the chain timing




Loosen the cam cover bolts,
then remove the cam cover

II

ENGINE - Dismantle




Loosen the taper plug for check the timing



Use the Rewind Starter Stopper clockwise rotate crankshaft then check chain timing



ALT rotor mark meet the accessory cover mark




When ALT mark correct , then check cylinder head sprocket have six pieces counter from cylinder head

six pieces


II

ENGINE - Dismantle

ACCESSORY COVER DISMANTLE



Loosen the accessory cover bolts



Raise the accessory cover by screwdriver from the prominence of case




When remove the accessory cover be care the spin nose antithrust spring and washer


II

ENGINE - Dismantle

DISCOMPRESSOR DISMANTLE



Loosen the discompressor mechanism bolt by open wrench



Pull out the discompressor mechanism



The discompressor mechanism, and notice the spring

II


ENGINE - Dismantle

ALTERNATOR ROTOR DISMANTLE




Loosen the ALT rotor nut
by air wrench


※The socket deep 85mm



Tighten Crankshaft Protector
to end on crankshaft



Tighten the ALT Puller to end
on ALT rotor




Tighten the CVT Puller on
ALT Puller by air wrench ,
then remove the ALT rotor


II

ENGINE - Dismantle


CAM SHAFT DISMANTLE




Loosen the tensioner cover ,
and notice the spring and
O-ring



Loosen the tensioner bolts ,
then remove the tensioner




Loosen the cam sprocket
bolts , then remove the cam
sprocket




Loosen the cam antithrust plate
Bolt , then remove the plate

II


ENGINE - Dismantle



Pull out intake and exhaust rock arm shaft by magnet



Pull out the cam shaft



The rock arms and cam thrust plate




The cam shaft


II

ENGINE - Dismantle

CHAIN DISMANTLE



Loosen the chain guide bolt ,
then remove the chain



Notice the boss




The chain


II

ENGINE - Dismantle

CYLINDER HEAD DISMANTLE




Loosen the cylinder head bolts



Remove the cylinder head , and notice the lock pins



Remove the gasket and chain guide




The cylinder head gasket and chain guide


II

ENGINE - Dismantle


BALANCER DISMANTLE




Loosen the balancer cover bolts



Raise the balancer cover by screwdriver from the prominence of case



Loosen the water pump idle pulley bolt and unclip the oil pump gear clip



The oil pump gear
The water pump idle gear

II

ENGINE - Dismantle




Loosen the balancer bolt by use screwdriver stop the balancer



The balancer

THE OIL PUMP DISMANTLE



Loosen the oil pump bolts and unclip the oil pump gear clip



The oil pump and back plate

II

ENGINE - Dismantle



Remove the spin nose and washer




II


THE DRIVESHAFT DISMANTLE



Loosen the front driveshaft yoke bolts , then remove the yoke




Loosen the front driveshaft seal cover bolts , then remove the cover



The yoke
The seal cover


ENGINE - Dismantle



Pull the front driveshaft and remove the 4WD gear



The 4WD gear



Remove the rear driveshaft yoke and seal cover
(same procedure of front driveshaft)




Loosen the starter bolts ,
then remove the starter



II

ENGINE - Dismantle



Loosen the shift drum cover bolts




Loosen the shift drum antithrust plate

THE OIL MAIN CIRCUIT DISMANTLE



Loosen the oil filter cover



Remove the oil filter

II

ENGINE - Dismantle




Loosen the main circuit bolt ,
then remove the main circuit




The main circuit

THE CYLINDER BLOCK DISMANTLE



Remove the rear driveshaft
yoke and seal cover



Turn the engine over , and
loosen the oil sump bolts

II

ENGINE - Dismantle



Use scraper and hammer to open the oil sump



The oil sump

※When reinstall must clean the surface of the oil sump



Loosen the crankcase bolts



Raise the crankcase by screwdriver from the prominence of case

II

ENGINE - Dismantle




The crankcase


※When reinstall must clean the surface of the crankcase

II


THE TRANSMISSION GEAR DISMANTLE



Remove the main shaft



Remove the lay shaft




Remove the rear shaft

ENGINE - Dismantle



The cylinder block

※When reinstall must clean the surface of the crankcase



Loosen the shift fork bolt , then pull out the shift fork shaft and remove the fork



The shift fork



Loosen the shift position rotor bolt , then remove the parking shaft plate

II

ENGINE - Dismantle



The parking shaft




Pull out the shift drum from the cylinder block



The shift drum

THE OIL RELEASE VALVE DISMANTLE



Loosen the oil release valve bolt , then remove the oil release valve by magnet

II


ENGINE - Dismantle




The oil release valve

II

THE CRANKSHAFT DISMANTLE



Loosen the connecting rod bolts



Remove the connecting rod cap , then remove the crankshaft



The cylinder block

※When reinstall must clean the surface of the crankcase


ENGINE - Dismantle

THE PISTON DISMANTLE



Pull out the piston

※Must clean the carbon on piston



Piston ring inspection
The second ring top side



Loosen the speed sensor bolt ,
then remove the speed sensor

II

ENGINE - Assembly


CAUTION :

Only trained and certificated technician can disassembly the CECTEK 500 EFI ENGINE. Improper disassembly may damage the engine. CECTEK can not provide the warranty to the engine which has not been properly disassembled and assembled by trained and certificated technician.


II

THE PISTON AND CONNECTION ROD ASSEMBLY

NO.	PART NAME	PART NO.
1.	CONROD ASSY.	40098013
2.	PISTON PIN	40090024
3.	CLIP	40090027
4.	PISTON-A	40096011
5.	PISTON-B	40096012
6.	PISTON RING TOP	40096013
7.	PISTON RING SECOND	40096014
8.	PISTON RING OIL CONTROL	40096015




1. Before assembly , must confirm if the piston (4,5) is matching the category of liner
2. A category piston only can be installed on A category liner
3. B category piston only can be installed on B category liner



4. Make sure the liner size mark on the cylinder block

ENGINE - Assembly

II



5.The piston size mark on top (A or B)

6.Confirm : when you face the piston , the piston (4,5) exhaust mark is in the down side



7.Confirm : the connecting rod (1) right side mark R is same side of piston


8.Install one clip (3) into the piston clip groove firmly

9.Install pin (2) into pin groove




10.Install the clip (3) into the other side groove to stop the pin (2)

11.Then sequentially install parts (8) , (7) , (6) , the crevice position of each ring as figure A shows





12.The opening of ring (8) of spacer shall be upward as figure B shows



ENGINE - Assembly

THE BALANCER ASSEMBLY



NO.	PART NAME	PART NO.
1.	RETAIN E-RING	RES009
2.	GEAR (37T)	40150030
3.	PIN	40130083
4.	BALANCER SHAFT ASSY.	40128004
 <p>figure A</p>		<p>1. Install pin (2) into balancer shaft (1)</p> <p>2. Install gear-oil pump driver (3) into balancer , reference to figure A</p>
		<p>3. Clip the E-ring (4) check the retain E-ring install into the groove of balancer shaft</p>

II

ENGINE - Assembly

THE BALANCER ASSEMBLY

NO.	PART NAME	PART NO.
1.	CRANKSHAFT	40110023
2.	KEY	40110108
3.	GEAR (36T)	40120018
4.	CAM CHAIN SPROCKET	41010004
5.	NUT (M30)	40110024


	<ol style="list-style-type: none"> 1. Install key (2) into crankshaft (1), keep the key parallel with crankshaft-taper 2. Install gear (3) into crankshaft (1), gear groove must be alignment key of crankshaft
<p>install long side into gear side</p>  <p>short side long side</p> <p>figure A</p>	<ol style="list-style-type: none"> 3. Install cam chain sprocket (4) into crankshaft (1), shall be install long side into gear side of crankshaft, reference to figure A 4. Screw nut (5) to crankshaft (1), tighten torque 250Nm

II

ENGINE - Assembly

THE MAIN SHAFT ASSEMBLY

NO.	PART NAME	PART NO.
1.	MAIN SHFAT	46030001
2.	BEARING	46030034
3.	SPACER	46010003
4.	LIP SEAL	40016004
5.	RETAIN C-RING	RCS025
6.	WASHER	46030010
7.	NEEDLE BEARING (CAGE TYPE)	46030030
8.	HIGH SPEED DRIVE GEAR (27T)	46030003
9.	LOW SPEED DRIVE GEAR (18T)	46030004
10.	NEEDLE BEARING (OPEN TYPE)	46030028



Before install gear and bearing , please lubricate with 10W/40 oil


- 1.Install bearing (2) into main shaft (1) , the bearing of ring side shall be install to main shaft of gear side
- 2.Install spacer (3) into main shaft , then install seal (4) into spacer (3)
- 3.Install a C-ring (5) into main shaft of groove , then put a washer (6) into main shaft
- 4.Install needle bearing (7) and high gear (8) into main shaft , shall be install high gear of raised side into main shaft of gear side
- 5.Install a washer (6) into main shaft then install C-ring (5) into main shaft of outside groove
- 6.Install low gear (9) into main shaft then install needle bearing (10) into main shaft , low gear of forl groove shall be in the outside

ENGINE - Assembly

II

THE LAY SHAFT ASSEMBLY

NO.	PART NAME	PART NO.
1.	LAY SHFAT	46030002
2.	CYLINDRICAL ROLLER BEARING	CRBNU1007NR
3.	NEEDLE BEARING (HALF CAGE TYPE)	46030031
4.	LOW SPEED DRIVEN GEAR (45T)	46030007
5.	RETAIN C-RING	RCS030
6.	HIGH SPEED DRIVEN GEAR (36T)	46030005
7.	WASHER	46030010
8.	HNEEDLE BEARING (CAGE TYPE)	46030030
9.	REVERSE DRIVEN GEAR (34T)	46030008
10.	RETAIN C-RING	RCS025
11.	ADJUSTING WASHER	46030016-26
12.	BEARING (DOUBLE ROW ANGULAR)	46030029
13.	WASHER	46030012
14.	WASHER	SCF060200883




Before install gear and bearing , please lubricate with 10W/40 oil

- 1.Install bearing (2) into lay shaft (1) , be shall install bearing of long side into bevel gear side
- 2.Install needle bearing (3) into lay shaft , then install low gear (4) into lay shaft , be shall install low gear (4) of plane into bevel gear side
- 3.Install retain C-ring (5) into lay shaft of groove
- 4.Install high gear (6) into lay shaft , be shall install high gear (6) of fork groove side into another bevel gear side

ENGINE - Assembly

II

THE LAY SHAFT ASSEMBLY



Before install gear and bearing , please lubricate with 10W/40 oil

5. Install washer (7) into lay shaft , then install needle bearing (8) into lay shaft
6. Install reversal gear (9) into lay shaft , then put a washer (7) into lay shaft , shall be install reversal gear (9) of groove side into bevel gear side
7. Install retain C-ring (10) into lay shaft of groove
8. Measure and calculate gear back clearance , then choose and install adjusting washer (11)
9. Install bearing (12) into lay shaft
10. Install washer (13) and screw flat head screw (14) into lay shaft , tighten torque 9Nm

ENGINE - Assembly

II

THE REAR DRIVESHAFT ASSEMBLY		
N0.	PART NAME	PART NO.
1.	DRIVE SHAFT ASSY.	46058001
2.	BEARING	DGB6205
3.	GEAR	46050023
4.	WASHER	46050007
5.	BOLT	BFH080251094
6.	WASHER	46050009-19
7.	BEARING	DGB6305
8.	O-RING	46050025

Before install gear and bearing , please lubricate with 10W/40 oil


- 1.Press the bearing (2) into the shaft (1) thoroughly.
- 2.Install the gear (3) into shaft (1)
- 3.Tighten the bolt(5) with washer (4) on the shaft (1) , the tighten torque 20Nm
- 4.Install the washer (6) which thickness shall be measured in advance into shaft (1) , then press the bearing (7) into shaft (1) , finally install the O ring (8)

ENGINE - Assembly

THE CYLINDER HEAD ASSEMBLY

N0.	PART NAME	PART NO.
1.	CYLINDER HEAD ASSY.	40058011
2.	VALVE STEM SEAL	40056002
3.	SEALING BALL	40070031
4.	HEXAGON SOCKET SCREW	SC050121291
5.	VALVE SPRING WASHER	40050140

II



Please clean up correlative parts and lubricate with 10W/40 oil


1. Knock the 2 balls (3) into cylinder head (1)
2. Paste the screw (4) with LT272 , tighten to cylinder head with 5Nm
3. Install the washer (5) on the valve spring seat
4. Knock valve stem seal (6) into valve guide , keep distance between the bottom of seal and the top of cylinder head within 12.7 ± 0.5 mm

ENGINE - Assembly

THE CYLINDER HEAD ASSEMBLY

N0.	PART NAME	PART NO.
1.	VALVE (INTAKE)	40050133
2.	VALVE (EXHAUST)	40050134
3.	SPRING	40050135
4.	SPRING CAP	40050136
5.	COTTER	40056003

II



Please clean up correlative parts and lubricate with 10W/40 oil

1.Install valve spring (3) x4 on the valve spring washer

2.Install cotter (5) x2 on the spring cap (4) (4pcs)


3.Install assembled spring cap (4) on the spring , with jig press it into the valve stem seals until a clear "click" sound was heard

4.check the cap is firmly installed on the stem with jig

ENGINE - Assembly

THE CYLINDER HEAD ASSEMBLY

N0.	PART NAME	PART NO.
1.	CAM SHAFT	40070068
2.	ROCKER ARM ASSY. (INTAKE)	40078016
3.	ROCKER ARM ASSY. (EXHAUST)	40078017
4.	SHAFT	40070063
5.	PLATE	40070065
6.	FLAT HEAD SCREW	SCF060160883



Please clean up correlative parts and lubricate with 10W/40 oil


- 1.Install cam (1) through cam bore
- 2.Install intake rocker (2) on the cam shaft , the rocker face toward intake side.
- 3.Install exhaust rocker (3) on the cam shaft , the rocker face toward exhaust side.
- 4.Install shaft rocker assy (4) x2 through intake rocker (2) and exhaust rocker (3)
- 5.Install the screw (6) through plate (5) and tighten to 9Nm , attention for the bottom of plate shall be clipped onto the groove of cam shaft.
- 6.Adjust the intake/exhaust valve gap to 0.3 mm.

ENGINE - Assembly

II

THE WATER PUMP ASSEMBLY

N0.	PART NAME	PART NO.
1.	ACCESSORY COVER	40010053
2.	MECHANICLA SEAL	40136011
3.	SHAFT	40130075
4.	PROPELLER	40130071
5.	WASHER	40130077
6.	PIN	40130083
7.	GEAR (35T)	40130063
8.	CAP	40070064
9.	RETAIN C-RING	RCS012




Please clean up correlative parts and keep dry

1.After install mechanical seal (2) on water pump shaft (3) and check the shaft have 12.1mm between mechanical seal and water pump shaft



ENGINE - Assembly

THE SHIFT DRUM AND FORK ASSEMBLY

N0.	PART NAME	PART NO.
1.	SHIFT DRUM ASSY.	46078002
2.	SHAFT (SHIFT FORK)	46070013
3.	SHIFT FORK (MAIN SHAFT)	46070001
4.	SHIFT FORK (LAY SHIFT)	46070002
5.	PARKING BREAK SHAFT	46070005
6.	THRUST PLATE	46070022
7.	BOLT	BFH060120884
8.	SHIFT LOCATING SPRING	46070015
9.	SPRING BLADE	46070014
10.	RETAIN C-RING	RCS010





ENGINE - Assembly


	<p>Shift locating rotor install position</p>
	<p>Install fork shift by plastic hammer and all parts lubricate</p>

II

THE TRANSMISSION GEAR ASSEMBLY

	<p>Install lay shaft to cylinder block</p>
	<p>Then push it to position</p>


ENGINE - Assembly




Install rear drive shaft to cylinder block , then push it to position



Install main shaft and push the needle bearing to position



Lubricate oil release valve and install valve 、 spring guide into cylinder block



Then tighten the bolt


※Torque 10Nm

II

ENGINE - Assembly

THE REAR IDLE GEAR ASSEMBLY

N0.	PART NAME	PART NO.
1.	SHAFT	46030009
2.	O-RING	46030027
3.	NEEDLE BEARING	46030032
4.	REVERSE GEAR (27T)	46030006
5.	WASHER	46030011
6.	RETAIN C-RING	RCH020





Please clean up correlative parts and lubricate with 10W/40 oil


ENGINE - Assembly

THE CRANKCASE AND CYLINDER BLOCK ASSEMBLY

N0.	PART NAME	PART NO.
1.	CRANKCASE	40018014
2.	MAIN BEARING (BLACK)	888.4001.607
3.	MAIN BEARING (NO COLOR)	888.4001.608
4.	MAIN BEARING (GREEN)	888.4001.609



ENGINE - Assembly



The cylinder block mark position , have 3 number

EX : 1 A 1

II

		CYLINDER BLOCK		
		1	2	3
CRANKCASE	A	N	B	B
	B	G	N	B
	C	G	G	N
N : No color G : Green B : Black				

Choose bearing color and install to crankcase

EX : cylinder block mark is 1 A 1
 crankcase mark is A 2 B

so we choose ALT side bearing color is No color (1&A)

1	A	1
A	2	B

and CVT side bearing color is Green (1&B)


1	A	1
A	2	B

※up and low bearing install the same color


ENGINE - Assembly

THE CRANKCASE AND CYLINDER BLOCK ASSEMBLY

N0.	PART NAME	PART NO.
1.	CYLINDER BLOCK	40018014
2.	MAIN BEARING (BLACK)	888.4001.613
3.	MAIN BEARING (NO COLOR)	888.4001.614
4.	MAIN BEARING (GREEN)	888.4001.615
5.	CONROD ASSY.	40098013
6.	BEARING (BLACK)	40096025
7.	BEARING (YELLOW)	40096024
8.	BEARING (BLUE)	40096023



II



CONNECTING ROD

Y : Yellow BL : Blue B : Black


EX : connecting rod mark is A
crankcase mark is A 2 B

A 2 B


※up and low bearing install the same color

ENGINE - Assembly


THE BEARING AND CRANKSHAFT ASSEMBLY




Lubricate all bearing



Install crankshaft



Lubricate all rotation position



Before tighten the two bolts ,
be lubricate connecting rod
bolts

※Torque 20Nm + 90° + 90°
(tighten the two bolts equally)

II

ENGINE - Assembly




Lay the Case Assembly Glue on cylinder block according figure A and glue diameter about 1mm


Figure A

Keep away the main gallery


Lay the glue diameter about 1mm



Glue Path



Main Gallery



Install crankcase to cylinder block

II

ENGINE - Assembly



Lubricate the bolt and washer, then tighten it

※Torque 35Nm + 90°
(tighten the bolts equally)



Install the cylinder block bolts



The tighten torque 20Nm



Install shift drum anti-thrust plate

※Torque 10Nm


II

ENGINE - Assembly




Lay the Case Assembly Glue on shift drum cover

※Glue diameter about 1mm




Install the shift drum cover

※Torque 10Nm



Reverse the engine , then tighten the cylinder bolt

※Torque 20Nm



Install the main circuit

※Torque 20Nm



ENGINE - Assembly

II



Lubricate the balancer




Install balancer gear ,
then check crankshaft
gear mark to balancer half
of gear position



Lay the Bolt Glue on the
bolt , then install the
balancer plate

※Torque 20Nm




Lubricate the oil pump and
rotor

ENGINE - Assembly

II



※ The bolts torque 10Nm




Install the oil pump gear , then clip the E-clip



Install the water pump idle gear , then tighten the bolt





※Torque 10Nm



Install the chain guide


※Torque 10Nm

ENGINE - Assembly

	<p>Install the chain guide into cylinder block and notice the lock position</p>
	<p>Install the cylinder head gasket and lock pins</p>
	<p>Install the cylinder head</p>
	<p>Lubricate the cylinder head bolts and washer</p>

II

ENGINE - Assembly




Tighten the cylinder bolts

※Torque 35Nm + 90° + 90°
(tighten the four bolts equally)


※The M6 bolts torque 10Nm



Lubricate cam shaft



Install the cam shaft into
cylinder head







Lubricate the rock arms and
shafts , then install into
cylinder head

II

ENGINE - Assembly

II

 <p>the mark</p>	<p>Check the crankshaft gear mark and balancer mark</p>
 <p>five gears</p>	<p>Between balancer mark to crankcase mark line have five gears</p> <p>crankshaft sprocket mark</p>
	<p>Crank sprocket mark must correct to blue mark of chain</p>
	<p>When crank sprocket mark correct , then check cylinder head sprocket have six pieces counter from cylinder head</p> <p>six pieces</p>


ENGINE - Assembly




Install the tensioner and tighten the bolts , then put the spring and screw the cover

※The bolts torque 10Nm

※The cover torque 10Nm





Install discompressor



Lay Bolt Glue LT272 on discompressor bolt , then screw it

※Torque 5Nm



Install the thermostat

※Torque 10Nm


II

ENGINE - Assembly



Install the cylinder head cover ,
then tighten the bolts

※Torque 10Nm




Install the spark plug

※Torque 10~12Nm



Lubricate the spin nose , then
install into cylinder block




Install the fly wheel assy. and
ALT rotor , then tighten the nut

※Torque 200Nm


II

ENGINE - Assembly

II




Check 4WD gear groove correct to low crankcase groove




Lay the Case Assembly Glue on accessory cover

※Glue diameter about 1mm



Install accessory cover , then tighten the bolts

※Torque 10Nm



Install the drive shaft seal cover , then tighten the bolts

※Torque 10Nm

ENGINE - Assembly




Lay the Bolt Glue on drive yoke bolt , then install drive yoke

※Torque 20Nm




Lay the Case Assembly Glue on balancer cover

※Glue diameter about 1mm



Install balancer cover , then tighten the bolts

※Torque 10Nm



Lay the Case Assembly Glue on oil sump cover

※Glue diameter about 2mm


II

ENGINE - Assembly




Install oil sump , then tighten the bolts

※Torque 10Nm




Install the CVT drive pulley , then tighten the bolt

※Torque 120Nm



Install the driven pulley , then tighten the bolt


※Torque 45Nm



Tighten the Belt Removal Tool to end to open the driven pulley , then install the belt

II

ENGINE - Assembly




Then rotate driven pulley
check the belt on position

※The driven pulley can
be free rotate



Install the CVT cover ,
then tighten the bolts

※Torque 10Nm



Install the rewind starter,
Then tighten the bolts

※Torque 10Nm



On Road Type



The engine assembly complete

II

CHASSIS


SEAT DISMANTLE.....	P1
AIR CLEANER COVER DISMANTLE....	P2
FRONT DECK DISMANTLE.....	P4
METER DISMANTLE.....	P5
FRONT COVER DISMANTLE.....	P7
LHS COVER DISMANTLE.....	P10
RHS COVER DISMANTLE.....	P13
HEAD LAMP DISMANTLE.....	P18
UPPER MUDFLAP DISMANTLE.....	P21
PROTECTOR DISMANTLE.....	P23
FOOT REST PEDAL DISMANTLE.....	P28
FRONT FENDER DISMANTLE.....	P30
INNER MUDFLAP DISMANTLE.....	P32
REAR LAMP DISMANTLE.....	P36
REAR COVER DISMANTLE.....	P40
TAIL LAMP ASSEMBLY DISMANTLE...	P47
ELECTRICAL HOUSING DISMANTLE..	P50
THROTTLE BODY DISMANTLE.....	P52
MUFFLER DISMANTLE.....	P56
FUEL PUMP DISMANTLE.....	P59
FUEL PUMP ASSEMBLY.....	P61

CHASSIS

SEAT DISMANTLE



Use the key to open the seat lock



Remove the seat



The seat




The tool bag under the seat

III

CHASSIS

AIR CLEANER COVER DISMANTLE



Dismantle the rivets,
and pull out the air cleaner
cover



⚠ Warning

Dismantle the connector of
main switch



Air cleaner cover assembly


III

CHASSIS

AIR CLEANER COVER DISMANTLE



Dismantle the cover,
then turn it over



Press the flange,
then remove the main switch



The main switch

III

CHASSIS

FRONT DECK DISMANTLE



Dismantle the rivets of front deck



Pull out the front deck



The front deck



The front box

III


CHASSIS

METER DISMANTLE



Dismantle the bolts of bracket

※Torque = 10 Nm



Push the pin to dismantle the connector



⚠ Warning
Be careful about the orange
O-ring of the wire harness
connector



The meter

III

CHASSIS

METER DISMANTLE



Dismantle the meter,
then turn it over



Dismantle the screws,
then remove the cover



The meter cover


III

CHASSIS

FRONT COVER DISMANTLE



Release the tenon from the brake oil reservoir



Pull out the brake oil reservoir



Dismantle the bolt

※Torque = 10 Nm



Dismantle the screws from two sides of the cover

III

CHASSIS


FRONT COVER DISMANTLE



Dismantle the screws under the front cover from the two sides of the cover



Pull out the front cover



⚠ Warning

Dismantle the connector of power supply



The front cover

III

CHASSIS

FRONT COVER DISMANTLE



Dismantle the front cover,
then turn it over



Turn counterclockwise to
dismantle the power supply



The power supply

III

CHASSIS


LHS COVER DISMANTLE



Dismantle the rivets & screw, then pull out the panel



The mudguard panel, LH



Dismantle the bolt & rivet, then pull out the left side cover



The side panel, LH

III

CHASSIS

LHS COVER DISMANTLE



Dismantle the screws



Release the tenon of left cover



Then pull out the cover



The side cover, LH

III

CHASSIS

LHS COVER DISMANTLE



Dismantle the bolts,
then remove the cover



The engine cover, LH

III

CHASSIS

RHS COVER DISMANTLE



Dismantle the rivet



Release the tenon,
then pull out the cover




The engine cover, RH

III

CHASSIS

RHS COVER DISMANTLE



Dismantle the rivets and screw, then remove the panel



The mudguard panel, RH



Dismantle the rivets, then remove the cover




The upper engine cover, RH

III

CHASSIS

RHS COVER DISMANTLE



Dismantle the bolt and rivet, then remove the panel



The panel



Dismantle the screws



Push the revolve lever from the cover inside

III


CHASSIS

RHS COVER DISMANTLE



Dismantle the center bolt from the revolve lever

※Torque = 10 Nm



Revolve lever alignment



Opposite side of revolve lever




The revolve lever and button

III

CHASSIS

RHS COVER DISMANTLE



Screw contraclockwise the shift bar (2/4WD) of the rod



The shift bar (2/4WD)



Release the tenon, then pull out the cover



The side cover, RH

III

CHASSIS

HEAD LAMP DISMANTLE



Dismantle the bolts


※Torque = 10 Nm



Dismantle the screws from the two sides of the cover



Dismantle the screws from the two side of the cover



⚠ Warning

Dismantle the head lamp connector

III

CHASSIS

HEAD LAMP DISMANTLE



The front nose



Turn it over



Press the tenon,
then remove the grille



The grille

III

CHASSIS

HEAD LAMP DISMANTLE



Dismantle the screws from the back of the lamp



Dismantle the screw from the front of the lamp



The head lamp assy



The head lamp angle adjustment bolt

※Upper = clockwise
Lower = counterclockwise

III


CHASSIS

UPPER MUDFLAP DISMANTLE



Dismantle the bolt

※Torque = 10 Nm



Pull out the tenon,
then remove the mudflap




The upper mudflap, R

III

CHASSIS

UPPER MUDFLAP DISMANTLE



Dismantle the bolt

※Torque = 10 Nm



Pull out the tenon,
then remove the mudflap



Upper mudflap, L

III

CHASSIS

PROTECTOR DISMANTLE



Dismantle the bolts,
Then remove the cover

※Torque = 10 Nm



The protector cover, RHF



Dismantle the bolts,
then remove the cover




The protector cover, LHF

III

CHASSIS

PROTECTOR DISMANTLE



Dismantle the bolts

※Torque = 10 Nm



Dismantle the bottom bolt,
then remove the cover

※Torque = 10 Nm




The protector cover, RHR

III

CHASSIS

PROTECTOR DISMANTLE



Dismantle the bolts

※Torque = 10 Nm



Dismantle the bottom bolt,
then remove the cover

※Torque = 10 Nm



The protector cover, LHR

III

CHASSIS

PROTECTOR DISMANTLE




Dismantle the bolts,
Then remove the cover

※Torque = 10 Nm



The front protector cover



Dismantle the bolts,
then remove the cover

※Torque = 10 Nm




The engine protector cover

III

CHASSIS

PROTECTOR DISMANTLE



Dismantle the rear bolts

※Torque = 10 Nm



Dismantle the bolts from two sides of the cover

※Torque = 10 Nm




The rear protector cover

III

CHASSIS

FOOT REST PEDAL DISMANTLE



Dismantle the rivets and screw of the front



Dismantle the rivets and screw of the rear



Dismantle the bottom bolts,
Then remove the right foot rest

※Torque = 10 Nm



The right foot rest

III

CHASSIS

FOOT REST PEDAL DISMANTLE



Dismantle the rivets and screw of the front



Dismantle the rivets and screw of the rear



Dismantle the bottom bolts, then remove the left foot rest

※Torque = 10 Nm




The left foot rest

III

CHASSIS

FRONT FENDER DISMANTLE



Pull out the tenon



Dismantle the upper bolt,
then remove the fender

※Torque = 10 Nm




The front fender, RH

III

CHASSIS

FRONT FENDER DISMANTLE



Pull out the tenon



Dismantle the upper bolt,
then remove the fender

※Torque = 10 Nm



The front fender, LH

III


CHASSIS

INNER MUDFLAP DISMANTLE



Dismantle the bolt

※Torque = 10 Nm



Pull out the tenon,
then remove the mudflap



The inner mudflap, RH

III

CHASSIS

INNER MUDFLAP DISMANTLE



The inner mudflap, RH



Dismantle the screws,
then remove the ventilator




The ventilator, RH

III


CHASSIS

INNER MUDFLAP DISMANTLE



Dismantle the bolt

※Torque = 10 Nm



Pull out the tenon,
then remove the mudflap



The inner mudflap, LH

III

CHASSIS

INNER MUDFLAP DISMANTLE



The inner mudflap, LH



Dismantle the screws,
then remove the ventilator



The ventilator, LH

III

CHASSIS

REAR LAMP DISMANTLE




Dismantle the rivet



Dismantle the bottom bolts of the bracket



 **Warning**
Dismantle the connectors



The rear lamp housing, RH

III

CHASSIS

REAR LAMP DISMANTLE



Turn the lamp housing over



Dismantle the bolts,
then remove the cover



The rear lamp cover, RH



The rear lamp, RH

III

CHASSIS

REAR LAMP DISMANTLE



Dismantle the screw



Dismantle the bottom bolts of the bracket



⚠ Warning
Dismantle the connectors



The rear lamp housing, LH

III

CHASSIS

REAR LAMP DISMANTLE



Turn the lamp housing over



Dismantle the screws,
then remove the cover



The rear lamp cover, LH



The rear lamp, LH

III

CHASSIS

REAR COVER DISMANTLE




Dismantle the bolts,
then remove the hooks

※Torque = 10 Nm



The hook, carrier



The hook alignment




Dismantle the bottom screws
from two sides of rear cover

III

CHASSIS

REAR COVER DISMANTLE



Dismantle the upper bolts

※Torque = 10 Nm



Screw out the fuel cap



⚠ Warning

Avoid any dirt,
Cover the fuel tank




The fuel cap

III


CHASSIS

REAR COVER DISMANTLE



Pull up the rear cover



 **Warning**

Avoid any dirt,
reinstall the fuel cap



The rear cover

III

CHASSIS

REAR COVER DISMANTLE



Turn over the rear cover



Dismantle the screws



Push the tenon,
then remove the cover



The rear cover, RH

III

CHASSIS

REAR COVER DISMANTLE



Turn over the rear cover



Dismantle the screws



Push the tenon,
then remove the cover



The rear cover, LH

III

CHASSIS

REAR COVER DISMANTLE



Dismantle the rear cover



The mesh



Turn over the rear cover,
then push the tenon



The meshes (RHS & LHS)

III

CHASSIS


REAR COVER DISMANTLE



Dismantle the rear cover



The slipproof on the rear cover



Turn over the rear cover,
then push the tenon to remove
the slipproof




The slipproof pad

III

CHASSIS


TAIL LAMP ASSEMBLY DISMANTLE



Pull out the wire,
then remove the seat wire



Dismantle the bottom bolt
from two sides of bracket



⚠ Warning

Dismantle the connector,
then remove the tail lamp



The tail lamp assy.


III

CHASSIS


TAIL LAMP ASSEMBLY DISMANTLE



Turn over the tail lamp



Pull out the plate of lock



⚠ Warning

When reinstall the wire,
make sure the wire into the
position



The lock

III

CHASSIS

TAIL LAMP ASSEMBLY DISMANTLE



Turn over the lamp



Dismantle the nuts

※Torque = 10 Nm



The tail lamp

III

CHASSIS

ELECTRICAL HOUSING DISMANTLE



⚠ Warning

Dismantle the negative wire,
to protect the electrical parts

※Torque = 10 Nm



Dismantle the connector



After dismantle all connector




Dismantle the nuts,
then remove the wire of start
relay

※Torque = 10 Nm


III

CHASSIS


ELECTRICAL HOUSING DISMANTLE




Dismantle the screws of fuse box



Remove the small wire harness



Lift the rear of electrical housing, to remove other wire harness




The electrical housing

III


CHASSIS

THROTTLE BODY DISMANTLE



Dismantle the bolts of air cleaner

※Torque = 10 Nm



Dismantle the connector of sensor



Release the screw of clamp



Release the screw of clip, then remove the hose and pull out the air cleaner

III

CHASSIS

THROTTLE BODY DISMANTLE



Pull out the air cleaner




The air cleaner


III

CHASSIS


THROTTLE BODY DISMANTLE



Dismantle the connector of IACV and TPS



Dismantle the bolts of throttle cable cover



⚠ Warning

Be careful about the O-ring of the throttle cable cover




The throttle cable cover


III

CHASSIS

THROTTLE BODY DISMANTLE



Release the nuts to loosen the throttle cable, then remove the throttle cable



Release the screw, then remove the throttle



⚠ Warning

Avoid any dirt,
Cover the intake pipe



The throttle

III


CHASSIS

MUFFLER DISMANTLE



Release the bolt of clip

※Torque = 15 Nm



Dismantle the bolts of muffler

※Torque = 25 Nm



Then remove the muffler



The muffler

III

CHASSIS

MUFFLER DISMANTLE




Check the gasket of muffler



The gasket



Dismantle the connector of
O2 sensor



Dismantle the nuts of exhaust
pipe

※Torque = 20 Nm

III

CHASSIS

MUFFLER DISMANTLE



Then remove the exhaust pipe



The exhaust pipe


III

CHASSIS

FUEL PUMP DISMANTLE



Use Spanner-Fuel Retainer to dismantle the retainer



Then turn counterclockwise



Pull out the fuel pump half way



Then turn counterclockwise


III

CHASSIS

FUEL PUMP DISMANTLE



Pull out the fuel pump




⚠ Warning

Turn counterclockwise,
then take out the fuel gauge
carefully



⚠ Warning

Be careful about the O-ring
of the fuel pump



The fuel pump


III

CHASSIS


FUEL PUMP ASSEMBLY




Install the O-ring,
then use oil to lubricate



Put in the fuel gage first



Then turn counterclockwise




Put in the fuel pump half way

III

CHASSIS


FUEL PUMP ASSEMBLY




Turn counterclockwise



And pull out the fuel pump
half way



Then put in the fuel pump to
end



Turn clockwise


III

CHASSIS

FUEL PUMP ASSEMBLY



Then install the retainer



⚠ Warning

Make sure the mark of fuel tank match the output pipe of fuel pump



Use the special tool to tighten the retainer



※Torque = 25 Nm

III

SUSPENSION / TRANSMISSION

DISMANTLE

FRONT WHEEL DISMANTLE.....	P1
FRONT CALIPER DISMANTLE.....	P2
FRONT HUB DISMANTLE.....	P3
FRONT DISK & COVER DISMANTLE....	P5
FRONT KNUCKLE DISMANTLE.....	P6
FRONT ABSORBER & UPPER ARM DISMANTLE.....	P9
FRONT LOWER ARM DISMANTLE.....	P10
FRONT DIFFERENTIAL DISMANTLE....	P11
REAR WHEEL DISMANTLE.....	P16
REAR CALIPER DISMANTLE.....	P17
REAR HUB DISMANTLE.....	P18
REAR DISK & KNUCKLE DISMANTLE..	P20
REAR ABSORBER & UPPER ARM DISMANTLE.....	P21
REAR LOWER ARM DISMANTLE.....	P22
REAR STABILIZER BAR DISMANTLE...	P23
REAR GEAR BOX DISMANTLE.....	P24

SUSPENSION / TRANSMISSION

LHF & RHF WHEEL DISMANTLE



Dismantle the nuts of wheel,
then remove the wheel

※Torque 60Nm



The wheel



/ Off Road /
Remove the wheel cap

/ On Road /
Push the cap from the back of
wheel



The wheel cap

IV


SUSPENSION / TRANSMISSION

LHF & RHF CALIPER DISMANTLE




Dismantle the upper bolt of caliper

※Torque 25Nm



Dismantle the lower bolt of caliper, then remove the caliper

※Torque 25Nm



Avoid any knock, suspend the caliper with cloth



Avoid any knock, suspend the caliper with cloth


IV

SUSPENSION / TRANSMISSION

LHF & RHF HUB DISMANTLE




Dismantle the pin of nut



Dismantle the nut of hub by

1.Reinstall the caliper,
then use brake to hold the
hub


※Torque 100Nm



Dismantle the nut of hub by

2.Reinstall the nuts of wheel,
then use big screw-driver to
hold the hub

※Torque 100Nm




The pin 、 nut and washer

IV


SUSPENSION / TRANSMISSION

LHF & RHF HUB DISMANTLE




⚠ Warning

The flange of washer is lower, when install the washer must in the right direction



⚠ Warning

The flange of washer is lower, when install the washer must in the right direction



Pull out the hub



The hub

IV

SUSPENSION / TRANSMISSION

LHF & RHF DISK & COVER DISMANTLE



Turn the hub over
dismantle the bolts of disk,
then remove the disk



The disk

※Torque 20Nm



Dismantle the bolts of cover,
then remove the cover




The cover

※Torque 10Nm

IV

SUSPENSION / TRANSMISSION

LHF & RHF KNUCKLE DISMANTLE




Turn the knuckle




Then dismantle the pin and nut of knuckle

※Torque 25Nm



The pin 、 washer and nut



Use the tool to dismantle the ball joint of tie rod

IV

SUSPENSION / TRANSMISSION

LHF & RHF KNUCKLE DISMANTLE




Dismantle the lower pin and nut of knuckle

※Torque 50Nm



The pin and nut



Use the tool to dismantle the ball joint of lower arm, then remove the knuckle

IV


SUSPENSION / TRANSMISSION

LHF & RHF KNUCKLE DISMANTLE



Dismantle the upper pin and nut of knuckle

※Torque 30Nm



The pin 、 washer and nut



Use the tool to dismantle the ball joint of upper arm




The knuckle

IV


SUSPENSION / TRANSMISSION

LHF & RHF ABSORBER & UPPER ARM DISMANTLE



Dismantle the nuts and bolts of absorber, then remove the absorber

※Torque 70Nm




The absorber



Dismantle the nut and bolt of arm, then remove the arm

※Torque 70Nm



The upper arm

IV


SUSPENSION / TRANSMISSION

LHF & RHF LOWER ARM DISMANTLE



Dismantle the nuts and bolts of arm, then remove the arm

※Torque 70Nm



The lower arm

IV

SUSPENSION / TRANSMISSION

FRONT DIFFERENTIAL DISMANTLE



Dismantle the bolt of differential to drain the gear oil



The bolt and washer

※Change new washer



⚠ Warning

By check the gear oil to know the state of differential



Then reinstall the bolt


IV

SUSPENSION / TRANSMISSION

FRONT DIFFERENTIAL DISMANTLE




Pull out the CV-Joint horizontally



Or use the screw-driver to open the CV-Joint



The CV-Joint




⚠ Warning
Avoid any dirty,
cover the differential

IV

SUSPENSION / TRANSMISSION


FRONT DIFFERENTIAL DISMANTLE



Dismantle the bolts of shaft


1. By use the screw-driver to lock the shaft

※Torque 25Nm



Dismantle the bolts of shaft

2. By shift the gear position to engage reverse gear and 4 wheel driver



Then pull out the shaft



The propeller shaft

IV

SUSPENSION / TRANSMISSION

FRONT DIFFERENTIAL DISMANTLE





⚠ Warning
Dismantle the connector of differential



Dismantle the nuts and bolts of differential

※Torque 40Nm



Lift the differential




Turn the counterclockwise side

IV

SUSPENSION / TRANSMISSION

FRONT DIFFERENTIAL DISMANTLE



Remove the differential



The differential

IV

SUSPENSION / TRANSMISSION

LHR & RHR WHEEL DISMANTLE



Dismantle the bolts of wheel,
then remove the wheel

※Torque 60Nm



The wheel



/ Off Road /
Remove the wheel cap

/ On Road /
Push the cap from the back of
wheel



The wheel cap

IV


SUSPENSION / TRANSMISSION

LHR & RHR CALIPER DISMANTLE




Dismantle the upper bolt of caliper

※Torque 25Nm




Dismantle the lower bolt of caliper, then remove the caliper

※Torque 25Nm



Avoid any knock, suspend the caliper with cloth




Avoid any knock, suspend the caliper with cloth


IV

SUSPENSION / TRANSMISSION

LHR & RHR HUB DISMANTLE




Dismantle the pin of nut



Dismantle the nut of hub by

- 1.Reinstall the caliper, then use brake to hold the hub


※Torque 100Nm



Dismantle the nut of hub by

- 2.Reinstall the nuts of wheel, then use big screw-driver to hold the hub

※Torque 100Nm




The pin 、 nut and washer

IV


SUSPENSION / TRANSMISSION

LHR & RHR HUB DISMANTLE




⚠ Warning

The flange of washer is lower, when install the washer must in the right direction



⚠ Warning

The flange of washer is lower, when install the washer must in the right direction



Pull out the hub



The hub

IV

SUSPENSION / TRANSMISSION

LHR & RHR DISK & KNUCKLE DISMANTLE




Turn the hub over and dismantle the bolts of disk, then remove the disk

※Torque 20Nm



The disk



Dismantle the nuts and bolts of knuckle, then remove the knuckle

※Torque 70Nm



The knuckle

IV


SUSPENSION / TRANSMISSION

LHR & RHR ABSORBER & UPPER ARM DISMANTLE



Dismantle the nuts and bolts of absorber, then remove the absorber

※Torque 70Nm




The absorber



Dismantle the nut and bolt of arm, then remove the arm

※Torque 70Nm




The upper arm

IV



SUSPENSION / TRANSMISSION

LHR & RHR LOWER ARM DISMANTLE



Dismantle the nuts and bolts of arm, then remove the arm

※Torque 70Nm



Use the open wrench to lock the ball joint, then dismantle the nut



The lower arm

IV

SUSPENSION / TRANSMISSION

REAR STABILIZER BAR DISMANTLE



Dismantle the bolts of bar from two sides

※Torque 30Nm




The stabilizer bar



Dismantle the nut of ball joint

※Torque 70Nm




The ball joint

IV

SUSPENSION / TRANSMISSION

REAR GEAR BOX DISMANTLE



Dismantle the bolt of gear box to drain the gear oil



The bolt and washer

※Change new washer



⚠ Warning

By check the gear oil to know the state of gear box



Then reinstall the bolt


IV

SUSPENSION / TRANSMISSION

REAR GEAR BOX DISMANTLE




Pull out the CV-Joint horizontally



Or use the screw-driver to open the CV-Joint



The CV-Joint




⚠ Warning
Avoid any dirty,
cover the differential

IV

SUSPENSION / TRANSMISSION


REAR GEAR BOX DISMANTLE



Dismantle the bolts of shaft

1. By use the screw-driver to lock the shaft

※Torque 25Nm



Dismantle the bolts of shaft

2. By shift the gear position to engage reverse gear



Then pull out the shaft



The propeller shaft

IV


SUSPENSION / TRANSMISSION

REAR GEAR BOX DISMANTLE





Dismantle the upper bolt of gear box

※Torque 25Nm



Dismantle the lower nuts and bolts of gear box

※Torque 40Nm



Lift the gear box




Turn the contraclockwise side

IV

SUSPENSION / TRANSMISSION

REAR GEAR BOX DISMANTLE



Then remove the gear box



The gear box

IV

ELECTRICAL


CONNECTOR.....	P1
WIRE CIRCUIT.....	P2
ECU PIN.....	P3
LAMP PIN.....	P4
DIFF PIN.....	P5
OTHER PIN.....	P6
ADJUSTMENT FOR TIRE CIRCUMFERENCE.....	P7
INJECTION PARTS POSITION.....	P9
ELECTRIC PARTS POSITION.....	P11
GROUND WIRE POSITION.....	P12

V

V



ELECTRICAL-Wire circuit



圖號日期: 980317

V

ELECTRICAL-ECU pin

ECM SYSTEM

NO.	SZ	CL	SYU	CIRCUIT				APPLI.
GNDP1	1. 25	B	CAVS	GND(F)		ECM HARN	PIN17	VBC(-)
GNDP2		B	CAVS	GND(F)		ECM HARN	PIN30	
IGN1		Y-L	CAVS	S/W ASSY-R		E/G RELAY		RELAY BOX
GND14		B	CAVS	E/G RELAY		GND(-)		
SFB		R	CAVS	SENSOR-FUEL CUT		E/G RELAY		SENSOR-FUEL CUT
SFC	0. 5	R-B	CAVS	SENSOR-FUEL CUT		ECM HARN	PIN11	
GND1		B	CAVS	SENSOR-FUEL CUT		GND(-)		INJECTOR DRIVER
INJB		R	CAVS	E/G RELAY		INJ CONN. TYPE		
INJ1	0. 5	L-Y	CAVS	INJ CONN. TYPE		ECM HARN	PIN28	IGNITION COIL SENSOR
COIB		R	CAVS	E/G RELAY		IGN COIL SNSR.		
EST1	0. 5	W	PEXCS	S03 IGN COIL SNSR.		ECM HARN	PIN27	O2 SENSOR (FR)
GND_IGN	1. 25	GR	CAVS	GND(-)		ECM HARN	PIN26	
O2HI	0. 5	P	CAVS	O2 SNSR. (FR)		ECM HARN	PIN23	
O2LO	0. 5	B-W	CAVS	O2 SNSR. (FR)		ECM HARN	PIN07	
O2B		R	CAVS	E/G RELAY		O2 SNSR. (FR)		
O2RA		Y-R	CAVS	O2 SNSR. (FR)		ECM HARN	PIN10	CRANK SENSOR
CNKP	0. 5	W	PEXCS	S01 CRANK SNSR.		ECM HARN	PIN31	
CNKN	0. 5	B	PEXCS	S01 CRANK SNSR.		ECM HARN	PIN32	INLET AIR TEMP. SENSOR
IAT	0. 5	Y-L	CAVS	IAT SNSR.		ECM HARN	PIN20	
GDS1	0. 5	B-W	CAVS	IAT SNSR.		ECM HARN	PIN07	COOLANT TEMP. SENSOR
CLT	0. 5	L-G	CAVS	CLT SNSR.		ECM HARN	PIN22	
GDS2	0. 5	B-W	CAVS	CLT SNSR.		ECM HARN	PIN07	TPS
V_REF	0. 5	R-L	AEX	TPS		ECM HARN	PIN06	
TPS	0. 5	Y	AEX	TPS		ECM HARN	PIN21	
GDS3	0. 5	B-W	AEX	TPS		ECM HARN	PIN07	IACV
IACV_AH	0. 5	R	AEX	IACV		ECM HARN	PIN24	
IACV_BL	0. 5	B-Y	AEX	IACV		ECM HARN	PIN34	
IACV_BH	0. 5	W-R	AEX	IACV		ECM HARN	PIN33	
IACV_AL	0. 5	R-L	AEX	IACV		ECM HARN	PIN25	FUEL PUMP & F/P RELAY
RLYP	1. 25	R-W	AEX	F/P RELAY		FUSE5		
FUP		G-R	CAVS	F/P RELAY		S/W ASSY-R		
FUEL_PM		O	CAVS	F/P RELAY		ECM HARN	PIN01	
PUMB	1. 25	R	CAVS	F/P RELAY		FUEL PUMP		
GND25	1. 25	B	CAVS	FUEL PUMP		GND(-)		FUEL PUMP & FLOAT
UNFP		LG-R	CAVS	SPEEDMETER	PIN24	FUEL PUMP		
GND17		B	CAVS	FUEL PUMP		GND(-)		DIAGNOSTIC
CAN_HI	0. 5	W-L	CAVS	DIAGNOSTIC		ECM HARN	PIN03	
CAN_LO	0. 5	B-R	CAVS	DIAGNOSTIC		ECM HARN	PIN04	
S12V	1. 25	G-R	AEX	DIAGNOSTIC		E/G RELAY		
GND_B	1. 25	B	CAVS	DIAGNOSTIC		GND(-)		
DIA	0. 5	L	CAVS	DIAGNOSTIC		ECM HARN	PIN05	
KLI	0. 5	Y	CAVS	DIAGNOSTIC		ECM HARN	PIN02	
RLYE	2. 0	Y	AEX	E/G RELAY		FUSE4		VBB
BAT1	1. 25	R-B	CAVS	FUSE5		ECM HARN	PIN09	
MIL	0. 5	Y-W	CAVS	SPEEDMETER	PIN09	ECM HARN	PIN14	MALFUNCTION INDICATOR LAMP
IGNK	0. 5	G	AEX	S/W ASSY-R		ECM HARN	PIN08	IGN_KEY
S01	0. 5	B	CAVS	POINT A		GND(F)		
S01	0. 5	B	CAVS	POINT B		GND(F)		
S01	0. 5	B	CAVS	CRANK SNSR.		ECM HARN		
CLT_GA	0. 5	G	CAVS	SPEEDMETER	PIN10	ECM HARN	PIN12	
TACHD	0. 5	W-L	CAVS	SPEEDMETER	PIN26	ECM HARN	PIN15	
RLN	0. 5	B	CAVS	S/W-OVERRIDE		ECM HARN	PIN19	OVERRIDE SWITCH
SIR1	0. 5	L	CAVS	S/W-OVERRIDE		SENSOR-GEAR POSITION		
DLR		R-W	CAVS	OTHER LIGHT RELAY		IGN. S/W		OTHER LIGHT RELAY
GND33		B	CAVS	OTHER LIGHT RELAY		GND(-)		
RLYD		Y-L	AEX	OTHER LIGHT RELAY		FUSE3		
S03	0. 5	B	CAVS	POINT E		GND(F)		
S03	0. 5	B	CAVS	POINT F		GND(B)		
S03	0. 5	B	CAVS	IGN COIL SNSR.		ECM HARN		

V

ELECTRICAL-Lamp pin

LAMP SYSTEM

NO.	SZ	CL	SYU	CIRCUIT			APPLI.
HDSW		R-W	CAVS	S/W ASSY-LM		IGN. S/W	HEAD LIGHT SWITCH
HDLD		W	CAVS	S/W ASSY-LM		HEADLIGHT RELAY(LD)	
GND16		B	CAVS	HEADLIGHT RELAY(LD)		GND(-)	
RLY1	1. 25	G-R	AEX	FUSE2		HEADLIGHT RELAY(LD)	HEAD LIGHT, LD & POSITION LAMP
HLG1	1. 25	G	CAVS	HEADLIGHT RELAY(LD)		HEADLAMP ASSY, R	
HLG2	1. 25	G	CAVS	HEADLIGHT RELAY(LD)		HEADLAMP ASSY, L	
PLG1		Y	CAVS	OTHER LIGHT RELAY		HEADLAMP ASSY, R	
PLG2		Y	CAVS	OTHER LIGHT RELAY		HEADLAMP ASSY, L	
PLG3		Y	CAVS	OTHER LIGHT RELAY		LAMP ASSY, P/I	TAIL LAMP & LAMP, LICENCE PLATE
LLG		Y	AEX	OTHER LIGHT RELAY		LAMP, LICENCE PLATE	
GND9		B	CAVS	HEADLAMP ASSY, R		GND(F)	
GND10		B	CAVS	HEADLAMP ASSY, L		GND(F)	GND, HEAD LAMP
GND19		B	AEX	REAR BREAK LAMP, R		GND(-)	GND, LAMP ASSY, REAR COMB
R10W		L-B	AEX	LAMP ASSY, D/I, RR		FLSHER LAMP, D/I	GND, LAMP, LICENCE PLATE
GND20	0. 5	B-W	AEX	LAMP, LICENCE PLATE		GND(-)	
L10W		B	AEX	LAMP ASSY, DI, RL		FLSHER LAMP, D/I	
GND34		B	AEX	REAR BREAK LAMP, L		GND(-)	
GND35		B	AEX	LAMP ASSY, P/I		GND(-)	
HDHI		L-G	CAVS	S/W ASSY-LM		HEADLIGHT RELAY(HI)	
GND15		B	CAVS	HEADLIGHT RELAY(HI)		GND(-)	
RLY2	2. 0	G	AEX	FUSE3		HEADLIGHT RELAY(HI)	HEAD LIGHT, HI
HLG3	1. 25	D	CAVS	HEADLIGHT RELAY(HI)		HEADLAMP ASSY, R	
HLG4	1. 25	D	CAVS	HEADLIGHT RELAY(HI)		HEADLAMP ASSY, L	
FVB		W	AEX	FUSE2		FLSHER SW, D/I	
FLS		W-R	AEX	FLSHER SW, D/I		FLSHER, VOL	FLASHER, DIRECTION INDICATOR
GND12		B	AEX	FLSHER SW, D/I		GND(-)	
FLS2		W-R	AEX	FUSE2		S/W ASSY-LF	
GND36		B	AEX	FLSHER, VOL		GND(-)	
DLG1		L	CAVS	S/W ASSY-LF		LAMP ASSY, D/I, FR	
R2W		Y-L	AEX	LAMP ASSY, D/I, FR		FLSHER LAMP, D/I	
DLG3		L-W	CAVS	S/W ASSY-LF		LAMP ASSY, D/I, RR	LAMP ASSY, DIRECTION INDICATOR
DLG2		D	CAVS	S/W ASSY-LF		LAMP ASSY, D/I, FL	
L2W		Y	AEX	LAMP ASSY, D/I, FL		FLSHER LAMP, D/I	
DLG4		L-B	AEX	S/W ASSY-LF		LAMP ASSY, D/I, RL	
SWB1		R-W	CAVS	SWITCH-BREAK/HAND(R)		E/G RELAY	
BLG1		L	CAVS	SWITCH-BREAK/HAND(R)		REAR BREAK LAMP, R	LAMP, BREAK/HAND(R)
BLG2		L	CAVS	SWITCH-BREAK/HAND(R)		REAR BREAK LAMP, L	
SWB2		R-W	CAVS	SWITCH-BREAK/HAND(L)		E/G RELAY	
BLG3		L	CAVS	SWITCH-BREAK/HAND(L)		REAR BREAK LAMP, R	LAMP, BREAK/HAND(L)
BLG4		L	CAVS	SWITCH-BREAK/HAND(L)		REAR BREAK LAMP, L	
SWBF		R-W	CAVS	SWITCH-BREAK/FOOT		E/G RELAY	
BLG5		L	CAVS	SWITCH-BREAK/FOOT		REAR BREAK LAMP, R	LAMP, BREAK/FOOT
BLG6		L	CAVS	SWITCH-BREAK/FOOT		REAR BREAK LAMP, L	
DLG5		L-W	CAVS	S/W ASSY-LF		LAMP, TOWAGE	
DLG6		L-B	CAVS	S/W ASSY-LF		LAMP, TOWAGE	
PLG5		Y	CAVS	OTHER LIGHT RELAY		LAMP, TOWAGE	
LLG1		Y	CAVS	OTHER LIGHT RELAY		LAMP, TOWAGE	
FLG		G-W	CAVS	HEADLIGHT RELAY(HI)		LAMP, TOWAGE	ALL KIND OF LAMP, TOWAGE
BLG7		L	CAVS	SWITCH-BREAK/HAND(L)		LAMP, TOWAGE	
BLG8		L	CAVS	SWITCH-BREAK/HAND(R)		LAMP, TOWAGE	
BLG9		L	CAVS	SWITCH-BREAK/FOOT		LAMP, TOWAGE	
GND26	1. 25	B	CAVS	GND(-)		LAMP, TOWAGE	
DH1		L-W	CAVS	DIODE2		S/W ASSY-LF	
DH2		L-B	CAVS	DIODE2		S/W ASSY-LF	
HZ1		L	CAVS	S/W ASSY-LM		DIODE2	
HZ2		L	CAVS	S/W ASSY-LM		DIODE2	

ELECTRICAL-DIFF pin

DIFF. CONTROL & STARTER IN GEAR UNIT

NO.	SZ	CL	SYU	CIRCUIT				APPLI.
RDSW	0.5	W	CAVS	S/W ASSY-R		DCU HARN1	P1-01	DCU HARN1
FDSW	0.5	G	CAVS	S/W ASSY-R		DCU HARN1	P1-02	
P/N	0.5	B-R	CAVS	DIODE1		DCU HARN1	P1-03	
D4WD	0.5	D	CAVS	SENSOR-GEAR POSITION(G2/4WD)		DCU HARN1	P1-04	
v=0	0.5	GR	CAVS	SPEEDMETER	PIN19	DCU HARN1	P1-05	
BRK	0.5	L	CAVS	SWITCH-BREAK/FDOT		DCU HARN1	P1-06	
FLK	0.5	Y	CAVS	DIFF. LOCK MOTOR(F)		DCU HARN1	P1-07	
FULK	0.5	Y-B	CAVS	DIFF. LOCK MOTOR(F)		DCU HARN1	P1-08	
RLK	0.5	LG-R	CAVS	DIFF. LOCK MOTOR(R)		DCU HARN1	P1-09	
RULK	0.5	LG-W	CAVS	DIFF. LOCK MOTOR(R)		DCU HARN1	P1-10	
RLED	0.5	P	CAVS	SPEEDMETER	PIN23	DCU HARN1	P1-11	
FLED	0.5	V	CAVS	SPEEDMETER	PIN13	DCU HARN1	P1-12	
VBD	0.5	R-W	CAVS	E/G RELAY		DCU HARN1	P1-13	
GND31	0.5	B	CAVS	GND(B)		DCU HARN1	P1-14	
GND29		B-W	AVX	GND(B)		DCU HARN2	P2-01	DCU HARN2
RLCR		L-W	AVX	DIFF. LOCK MOTOR(R)		DCU HARN2	P2-02	
RUCR		L	AVX	DIFF. LOCK MOTOR(R)		DCU HARN2	P2-03	
RIGN		R-W	AVX	FUSE7		DCU HARN2	P2-04	
GND30		B-W	AVX	GND(B)		DCU HARN2	P2-05	
SCR		B-R	AVX	STARTER RELAY		DCU HARN2	P2-06	
DSIN		B	AVX	GND(B)		DCU HARN2	P2-07	
FIGN		R	AVX	FUSE7		DCU HARN2	P2-08	
FUCR		G-W	AVX	DIFF. LOCK MOTOR(F)		DCU HARN2	P2-09	
FLCR		G	AVX	DIFF. LOCK MOTOR(F)		DCU HARN2	P2-10	
BATP	3.0	R	AEX	BAT(+)		FUSE4		
GND27		B	CAVS	DIFF. LOCK MOTOR(R)		GND(-)		
GND28		B	CAVS	DIFF. LOCK MOTOR(F)		GND(F)		
GND32		B	CAVS	S/W ASSY-R		GND(F)		
ERL	0.5	B	CAVS	ECM HARN	PIN19	DCU HARN1	P2-16	
BATM	3.0	R	AEX	BAT(+)		FUSE1		

V

ELECTRICAL-Other pin

STARTER & CHARGE SYSTEM and OTHER

NO.	SZ	CL	SYU	CIRCUIT			APPLI.
IVB1		R	AEX	FUSE4	IGN. S/W		STATER RELAY
IVB2		R	AEX	FUSE4	IGN. S/W		
BAT2		R-B	CAVS	FUSE5	SPEEDMETER	PIN21	
IGSL		B-W	CAVS	STARTER RELAY	S/W ASSY-LF		
DID		B-R	CAVS	STARTER RELAY	DIODE1		
GVB	3. 0	R	AEX	RECTIFIER ASSY	FUSE1		RECTIFIER ASSY
GND3	2. 0	B	AEX	RECTIFIER ASSY	GND(B)		
RTA	1. 25	G	CAVS	RECTIFIER ASSY	E/G RELAY		
FUS	1. 25	W	AEX	FUSE8	E/G RELAY		IGNITION FUSE
EGSW		Y-L	AEX	IGN. S/W	S/W ASSY-R		
SPB	0. 5	B	PEXCS S02	SPEED SENSOR	SPEEDMETER	PIN18	
SPS	0. 5	W	PEXCS S02	SPEED SENSOR	SPEEDMETER	PIN25	SPEED SENSOR
GND2		B-W	CAVS	SPEED SENSOR	SPEEDMETER	PIN17	
FAN	1. 25	GR	CAVS	FAN	FAN RELAY		
GND7	1. 25	B	CAVS	FAN	GND(A)		COOLING FAN MOTOR
TMT		R-W	CAVS	FAN-THERMOSTAT	E/G RELAY		
TFR		Y-L	CAVS	FAN-THERMOSTAT	FAN RELAY		
RLYF	1. 25	W	AEX	FUSE6	FAN RELAY		
GND13		B	CAVS	FAN RELAY	GND(-)		
HON1		R-B	CAVS	S/W ASSY-LF	FUSE5		HORN
HON2		G	CAVS	S/W ASSY-LM	HORN		
GND5		B	CAVS	HORN	GND(F)		
POS	1. 25	R-W	AEX	FUSE8	POWER SOURCE		POWER SOURCE
GND4	1. 25	B	AEX	POWER SOURCE	GND(F)		
SIGP		Y	CAVS	SENSOR-GEAR POSITION	SPEEDMETER	PIN04	SENSOR-GEAR POSITION
SIGR		Y-R	CAVS	SENSOR-GEAR POSITION	SPEEDMETER	PIN05	
SIGN		Y-G	CAVS	SENSOR-GEAR POSITION	SPEEDMETER	PIN06	
SIGH		Y-B	CAVS	SENSOR-GEAR POSITION	SPEEDMETER	PIN07	
SIGL		Y-L	CAVS	SENSOR-GEAR POSITION	SPEEDMETER	PIN08	
GND23	1. 25	B	CAVS	SENSOR-GEAR POSITION	GND(B)		SPEEDMETER
VBSP		R-W	AEX	E/G RELAY	SPEEDMETER	PIN20	
GND6		B	CAVS	GND(F)	SPEEDMETER	PIN14	
DRSP		L-W	CAVS	FLSHER SW, D/I	SPEEDMETER	PIN03	
DLSP		L-B	CAVS	FLSHER SW, D/I	SPEEDMETER	PIN02	
HDSP		L-G	CAVS	S/W ASSY-LM	SPEEDMETER	PIN01	
DPS		GR	CAVS	OIL/P. S/W	SPEEDMETER	PIN11	
4WD		D	CAVS	SENSOR-GEAR POSITION(2/4WD)	SPEEDMETER	PIN12	
GND24		B	CAVS	SENSOR-GEAR POSITION(2/4WD)	GND(B)		
S02	0. 5	B	CAVS	POINT D	SPEED SENSOR(GND2)		
S02	0. 5	B	CAVS	POINT C	GND(F)		
S02	0. 5	B	CAVS	SPEED SENSOR	SPEEDMETER		
SIP1		Y	CAVS	DIODE1	SENSOR-GEAR POSITION		SENSOR-GEAR POSITION
SIN1		Y-G	CAVS	DIODE1	SENSOR-GEAR POSITION		
WIN		R-W	CAVS	E/G RELAY	WINCH		WINCH
STAL		Y-L	CAVS	IGN. S/W	S/W ASSY-LF		
BACK		LG-W	CAVS	OTHER LIGHT RELAY	SPEEDMETER	PIN22	SPEEDMETER
HZRD		L	CAVS	DIODE2	SPEEDMETER	PIN16	

V

Adjustment Tire Circumference

ADJUSTMENT FOR TIRE CIRCUMFERENCE




Turn off the main switch



Dismantle the connector of speedometer



Turn on the main switch



Press the two buttons at the same time

V

Adjustment Tire Circumference

ADJUSTMENT FOR TIRE CIRCUMFERENCE



Install the connector of speedometer



Release the two button at the same time while install the connector of speedometer, then show the three-figure number

(The Tire Circumference)



A : shift the flashing position of number

B : increase the flashing number

On Road : 556 / Off Road : 646





Press and release the two Buttons at the same time, then the speedometer will auto restart to normal function

Injection Parts Position (1)

THROTTLE BODY




INJECTOR



ECU (ECM)




O2 SENSOR




Injection Parts Position (2)


SPARK PLUG



IGNITION COIL



FUEL CUT SENSOR



WATER TEMP. SENSOR




Electric Parts Position

OIL PRESS. SENSOR




HORN



FUEL PUMP




RECTIFIER




Ground Wire Position

Maintenance Step

1. Dismantle the wire
2. Use the sand-paper to clean the position
3. Use the sand-paper to clean the ground wire
4. Lay the grease on the position and wire



MAINTENANCE



Regular Maintenance Table.....	P1
Engine Oil Type.....	P2
Differential Oil Type.....	P4
Coolant Type.....	P6
Engine Torque Table.....	P8
Chassis Torque check.....	P9
Spark Plug Exchange.....	P11
Oil Filter Exchange.....	P13
Air Filter Exchange.....	P15

Regular Maintenance table

ITEM	300km	1500km	3000km	6000km
ENGINE				
Engine Oil	R	R	R	R
Engine Oil Filter	R	R	R	R
Valve Adjustment	I		I	
Coolant Water	I		I	R
CVT Drive Belt		I	R	
FUEL				
Air Filter		C	R	R
Throttle Body	I	I	I	I
ELECTRICAL				
Spark plug	I	I	R	R
Battery	I		I	
Control Switches	I	I	I	I
Lights	I	I	I	I
DRIVE				
Front Propeller	I	L / I	L / I	L / I
Rear Propeller	I	L / I	L / I	L / I
Steering	I		I	I
Differential Oil	R	I	I	R
Wheel Nut	I	I	I	I
BRAKE				
Brake System	I		I	I
Brake Pad	I	I	I	I
BODY				
A Arms	I	L / I	L / I	L / I
Absorbers		I		I


※ I : Inspect / C : Clean / L : Lubricate / R : Replace

Engine Oil Type

The Engine Original Oil Type : 10w / 40


※The viscosity of oil should follow the temperature range of your area according to below chart.

※Recommended engine oil classification API service SJ type or higher



Total Engine Oil Capacity (with filter) : 3500cc

Engine Oil Type



※The Engine Oil Drain Bolt Torque = 20 Nm

※Put The Vehicle On The Flatland.

Make Sure The Oil Level Between Max and Min Level Of Dipstick, While Engine Is Cold.

Differential Oil Type

The Front and Rear Differential Gear
Original Oil Type : PENNZOIL 80w / 90

※The approved oil :
PENNZOIL 4096 80w / 90


SAE GRADE	80W-90
API SERVICE	GL-5
GRAVITY,API	26
VISCOSITY@40°C, cSt	150
VISCOSITY@100°C, cSt	14.5
VISCOSITY INDEX	95
POUR POINT, °C	-26
FLASH POINT, °C	204
COLOR	5

※Use a SAE 80w / 90 hypoid oil on API
classification GL-5 to fill the differential.

Total Differential Oil Capacity : 325 ± 20cc

VI

Differential Oil Type




VI

Coolant Type

THE RADIATOR

N0.	PART NAME	PART NO.
1.	RADIATOR ASSY.	60046001
2.	BOLT	BFH060200884
3.	CAP ASSY.	60046002
4.	BOLT	BFH060120882
5.	HOSE, RADIATOR OUTLET	60040005
6.	CLIP	CC02003209
7.	HOSE, RADIATOR INLET	60040004
8.	CLIP	CC02504009




A Connect to Thermostat Cover

B Connect to Water Pump Cover

Coolant Type

The Coolant type : Ratio 50:50
(50%water / 50%antifreeze)

Required engine coolant solution capacity	
Total capacity	3550c.c.
Engine Coolant	1775c.c.
Water	1775c.c.



A Radiator Cap B Reservoir Tank Cap

※Make Sure The Coolant Between Max And Min Level Of Reservoir Tank, While Engine is Cold.


VI

Engine Torque Table

ITEM	POSITION	TORQUE
Chain Sprocket	II - 28	250Nm
Lay Shaft Flat Head	II - 31	9Nm
Rear Drive Shaft	II - 32	20Nm
Oil Release Valve	II - 39	10Nm
Rod	II - 45	20Nm + 90° + 90°
Engine Block (M10)	II - 47	35Nm + 90°
Engine Block (M8)	II - 47	20Nm
Engine Block (M6)	II - 48	10Nm
Shift Drum Plate	II - 47	10Nm
Shift Drum Cover	II - 48	10Nm
Main Circuit	II - 48	20Nm
Balancer Plate	II - 49	20Nm
Oil Pump	II - 50	10Nm
Water Pump Gear	II - 50	10Nm
Chain Guide	II - 50	10Nm
Cylinder Head (M10)	II - 52	35Nm + 90° + 90°
Cylinder Head (M6)	II - 52	10Nm
Tensioner	II - 54	10Nm
Discompressor	II - 54	5Nm
Thermostat	II - 54	10Nm
Cylinder Head Cover	II - 55	10Nm
Spark Plug	II - 55	12Nm
Alternator	II - 55	200Nm
Accessory Cover	II - 56	10Nm
Drive Shaft Seal Cover	II - 56	10Nm
Drive Yoke	II - 57	20Nm
Balancer Cover	II - 57	10Nm
Oil Sump	II - 58	10Nm
CVT Drive Pulley	II - 58	120Nm
CVT Driven Pulley	II - 58	45Nm
CVT Cover	II - 59	10Nm

VI


Chassis Torque Check



ITEM	TORQUE
1.LHF Suspension Bolts x 2	70 N-m
2.LHF Caliper Bolts x 2	25 N-m
3.LHF Wheel Rim Nuts x 4	60 N-m
4.Front Differential Bolts x 2	40 N-m
5.LHS Engine Bolts x 2	45 N-m
6.LHS Footrest Bolts x 4	40 N-m
7.Rear Propeller Shaft Bolts x 8	25 N-m
8.LHR Wheel Rim Nuts x 4	60 N-m
9.LHR Caliper Bolts x 2	25 N-m
10.Rear Differential Bolts x 3	40 N-m
11.LHR Suspension Bolts x 2	70 N-m
12.Rear Muffler Bolts x 2	20 N-m

VI

Chassis Torque Check




ITEM	TORQUE
1.RHR Suspension Bolts x 2	70 N-m
2.RHR Caliper Bolts x 2	25 N-m
3.RHR Wheel Rim Nuts x 4	60 N-m
4.RHS Footrest Bolts x 4	40 N-m
5.RHS Engine Bolts x 2	45 N-m
6.Front Propeller Shaft Bolts x 8	25 N-m
7.RHF Wheel Rim Nuts x 4	60 N-m
8.RHF Caliper Bolts x 2	25 N-m
9.RHF Suspension Bolts x 2	70 N-m
10.Front Muffler Bolts x 2	20 N-m


VI

MAINTENANCE-Spark Plug

SPARK PLUG EXCHANGE



Dismantle the screws and bolt of LHS upper mudflap



Then remove the LHS upper mudflap



Pull out the spark plug hat



Clean up around the spark plug, then dismantle the spark plug

VI

MAINTENANCE-Spark Plug

SPARK PLUG EXCHANGE



The spark plug

※Type : Champion PRG7C

※ Gap : 0.6~0.7mm




Assemble The spark plug

※Torque 12N-m

VI

MAINTENANCE-Oil Filter


OIL FILTER EXCHANGE



From the LHS of vehicle,
after dismantle the LHS
engine cover



Or from the RHS of vehicle



Clean up around the oil filter
cover to avoid any dirt,
then dismantle the cover




Pull out the oil filter,
then clean the old oil inside

VI

MAINTENANCE-Oil Filter

OIL FILTER EXCHANGE



Assemble the new oil filter,
use some oil lubricate the front
rubber of filter



Push the oil filter to end,
then add some oil to the filter



Before assembly the cover,
lubricate the O-ring



Tighten the cover to end

VI

MAINTENANCE-Air Filter

AIR FILTER EXCHANGE



Dismantle
1.The air cleaner cover
2.The front deck
3.The front cover



Push the revolve lever from
the cover inside



Dismantle the center bolt from
the revolve lever




Screw counterclockwise the
shift bar (2/4WD) of the rod

VI

MAINTENANCE-Air Filter

AIR FILTER EXCHANGE




Release the RHS tenon



Release the LHS tenon



Dismantle the LHS bolt of
seat holder



Dismantle the RHS bolts of
seat holder

VI

MAINTENANCE-Air Filter

AIR FILTER EXCHANGE



The seat holder



Release the clips of cover,
then remove the air cleaner
cover



Pull out to open the clip



Change the air filter

VI

SPECIAL TOOLS

TOOL PHOTO	TOOL NUMBER & NAME
 A collection of diagnostic tools including a silver braided USB cable, a black diagnostic cable, a CD-ROM in its jewel case, and a small black electronic module.	991000001 EMS DIAGNOSTIC KIT ASSY. ※Include : 991000002 991000003 991000004
 A CD-ROM in its jewel case, featuring the CECTEK logo and a motorcycle image.	991000002 EMS DIAGNOSTIC SOFTWARE
 A black diagnostic cable with a blue connector on one end and a black connector on the other.	991000003 EMS DIAGNOSTIC CABLE
 A silver braided USB cable with a standard USB-A connector on one end and a black diagnostic connector on the other.	991000004 EMS DIAGNOSTIC USB ADAPTOR

VII

SPECIAL TOOLS

TOOL PHOTO	TOOL NUMBER & NAME
	<p>991000005 REMOVER – ALTERNATOR ROTOR ASSY.</p> <p>※Include : 991000006 991000007 991000008</p>
	<p>991000006 CRANKSHAFT PROTECTOR</p>
	<p>991000007 HOLDER – ALTERNATOR REMOVER</p>
	<p>991000008 PULLER – CVT & ALTERNATOR</p> <p>M12 * 1.5</p>

VII

SPECIAL TOOLS

TOOL PHOTO	TOOL NUMBER & NAME
	992000001 SPANNER – FUEL RETAINER
	992000002 REWIND STARTER STOPPER
	888.4002.653.B1 CASE ASSEMBLY GLUE (1207F) Brand : ThreeBond Type : 1207F (Liquid Gasket Black Silicone Type) Volume : 333ml
	888.4002.670.B BOLT GLUE (T272) Brand : Loctie Type : 272 Volume : 250ml

VII



CECTEK

<http://www.cectekpowersports.com/>